MINI FLIP DIGITAL CAMERA

LK-027 | Instructions



GETTING STARTED

1. Charge through the USB-C port using a 5 V / 2 A power supply. The red light stays on while charging and switches off when charging is complete. Allow about 1.5–2 hours.
2. Insert a compatible TF/microSD card. A memory card is required to take photos or record video. Format a new card in Settings before use. Back up files first: formatting erases the card.
3. Press and hold the Power button to switch on. Flip up the screen to frame your picture.

TRANSFER YOUR FILES

Connect the camera to a computer with a USB cable that supports data transfer to access the memory card.

AT A GLANCE

1.47-inch display • JPG photos / AVI video • 1080p or 720p video • USB-C, DC 5 V.

Photo resolution settings: 1, 2, 3, 5, 8, 12, 16, 18, 20 or 48 MP.

Approximate dimensions: 51.97 × 25.98 × 36.49 mm.

Colour may vary.

CONTROLS

Power: hold to switch on; press briefly to open settings or change the playback mode.

Photo: press briefly to take a photo or record video; hold to switch between photo, video and playback modes.

Up: press to change filters while shooting or move up in settings. Hold to switch the flash on or off.

Down: press to change filters while shooting or move down in settings.

Reset: if the camera freezes or the screen is abnormal, briefly press the recessed reset button with a suitable pin to force a shutdown and reset.

CARE & SAFETY

- Contains small parts. Keep these instructions for future reference.
- The built-in battery is not removable. Charge under adult supervision.
- Keep away from fire, high temperatures and damp conditions.
- Stop using the camera if it is visibly damaged.
- During long-term storage, recharge once a month.