

RC OFF-ROAD MONSTER TRUCK

QX3688-12 | Control quick reference

REMOTE CONTROL


Power switch	ON / OFF
Left circular button	High / low speed
Middle circular button	Lights
Right circular button	Music
Steering wheel	Turn left / right
Trigger	Forwards / reverse

BATTERIES SHOWN IN THE SOURCE



Remote: 2 × 1.5 V AA batteries, not included.
Fit the batteries according to the + and – markings inside the compartment.

BATTERIES SHOWN IN THE SOURCE



Vehicle: 1 × 7.4 V battery pack.
Use only the correct battery and charging accessories specified for this vehicle.

REFERENCE NOTE

This sheet explains the supplied control and battery diagram. The source does not specify charging procedures, pairing steps or complete safety instructions. Check the full manufacturer manual and charger label before charging or operating the vehicle.
Keep these instructions for future reference.