GADGET CARE

CARE FOR EVERY GADGET.

DUST

CORDLESS AIR BLOWER

ZY-2100-SE | Instructions



GETTING STARTED

1. Check the blower, battery and charging accessories for damage before use.
2. Keep the air inlet and outlet clear.
3. Press and hold the power button to blow air. Release it to stop.

CHARGING

Use only the battery and charging accessories supplied or specified for this exact model. The manual describes both cradle and cable charging methods, follow the instructions on your supplied charger.

The manufacturer lists approximately 2.5 hours charging time. Do not overcharge or excessively discharge the battery.

CARE & STORAGE

- Store in a dry place out of reach of children and pets.
- Keep away from direct sunlight, high temperatures and hot vehicles.
- Remove debris from the air inlet and outlet regularly.
- Do not insert nails or sharp objects into either opening.
- Do not clean with alcohol, nail-polish remover or detergents that can damage the casing.

SAFETY

- Keep dry. Do not immerse in water or use with wet hands.
- Keep away from baths, showers, basins and other water containers.
- Never block the inlet or outlet or insert foreign objects while operating.
- Keep hair away from the air inlet.
- Do not use near petrol vapours, flammable sprays, solvents or paint thinners.
- Do not leave the blower running unattended.
- Do not use damaged or overheating charging cables. Do not pull, twist, bend, crush or modify the cable. Replace damaged cables before charging.
- Stop using immediately if airflow stops, the unit repeatedly shuts down, overheats, glows internally or produces smoke.

MODEL INFORMATION

Manufacturer model: ZY2100-SE
Rated working voltage: 21 V

Keep these instructions for future reference.